

## ► CAC | MECHANICAL DETAILS & DRAWINGS

### CAC | Mechanical Information Table


MODEL	Overall Width (in.)	Nozzle Width (in.)	Mounting Width (in.)
CAC-1-36	37	36	36.06
CAC-1-42	43	42	42.06
CAC-1-48	49	48	48.06
CAC-1-60	61	60	60.06
CAC-2-60	61	60	60.06
CAC-2-72	73	72	72.06
CAC-2-84	85	84	84.06
CAC-2-96	97	96	96.06
CAC-3-108	109	108	108.06
CAC-3-120	119	118	118.06
CAC-3-132	134	133	133.06
CAC-4-144	146	145	145.06




### NOTE

Powered Aire recommends that the junction box be installed on the same side of the opening as the door motor. The Air Controller™ will be on the opposite side. When placing an order, please include on the purchase order whether the door motor is on the left or right side of the opening.


\*The drawing below is for a door motor on the right side of the opening.



### TOP



### FRONT



### BOTTOM

